

FENDER TRIM APPLICATION INSTRUCTIONS

- 1. CLEAN SURFACE:** The area where the product will be applied should be free of wax, dirt or foreign substance. Use Isopropyl alcohol for best results.
- 2. SURFACE TEMPERATURE:** The surface where the product is to be installed should be at least 75 deg. F/25 deg. C for proper adhesion. If needed, the surface can be warmed.
- 3. STORAGE:** Material should be stored in a warm place prior to installation for flexibility. Also, it should be stored out of direct sunlight prior to installation.
- 4. INSTALLATION:** Cut the molding for your starting point to the proper angle using scissors or pruning shears. Peel back the red poly liner exposing adhesive. Be careful not to allow exposed adhesive to become contaminated. Apply molding to your desired edge.

Continue to peel and apply until you have finished your install.

DO NOT BE ALARMED IF THE RED TAPE IS CURLED. THIS IS NORMAL AND DOESN'T AFFECT ADHESION.