

- \* Allow a 1" Overlap where all sheets come together.
- \* Save all scraps until project is complete.
- \* Watch our 6 part video series above before starting your install.
- \* This is a dry mount application, Do Not apply wet!
- \* See the back side of each sheet for placement location on golf car.

