

- * Save all scraps until install is complete.
- * allow a 1" overlap where each sheet comes together.
- * See back side of each sheet for placement label.
- * DO NOT install wet.

Front Cowl Center

- * Follow Installation instructions provided.
- * Watch all 6 installation videos in order before starting.